





Assembly Manual






























V1.1 (25 Dec 2018)


















V1.1 (25 Dec 2018)
























Caution when install the Front Body Mount

A Caution: Not included Trim this part to avoid the touch of front belt

FFZ Gear Ratio Chart

		Motor Pinion					
		13	14	15	16	17	18
Spur Gear	39	5.4	5.01	4.68	4.39	4.13	3.9
	40	5.54	5.14	4.8	4.5	4.24	4
	41	5.68	5.27	4.92	4.61	4.34	4.1

Recommend Gear ratio for Atomic Motors:

3500KV : around 4.3 ~ 4.6

5500KV : around 5.2 ~ 5.5

Gear ratio decision is affected by strength of battery, and overall smoothness of the

transmission system also the size of the track